

## Inva Flexi Platform Lift

**Q. Do I need to have 3 phase electric supply to the lift?**

A. No. Our lift only requires a normal 240V, 16Amp supply.

**Q. Do I need a pit.**

A. No. The unit does require a solid and level base.

**Q. What is the maximum travel height?**

A. The unit will serve from 500mm to 3 metres.

**Q. What is the maximum load?**

A. Maximum working load is 300Kg /

**Q. What guarantee do you provide?**

A. Standard 12 month parts and labour on the whole lift.

**Q. What installation width do you need?**

A. We need 1500mm.

**Q. What type of controls does the unit have?**

A. Constant pressure buttons when travelling on the lift.

**Q. Can I personalise my lift?**

A. Yes. We can offer the lift in different colours, key locking, automatic doors and other options.

**Q. Can I change the floor covering in the lift?**

A. Yes- we have a number of coverings you can choose from.

**Q. How fast is it?**

A. The unit travels at 0.06m/second

**Q. Do you need a supporting wall?**

A. Yes. The front facing wall will need to be structural as we will be fixing the unit to the wall at points 150mm down from the top threshold.

**Q. How long does an installation take?**

A. On average a lift would normally be completed in 1-2 days on site.

**Q. Am I able to have a lift with an open adjacent arrangement?**

A. Yes. The door on the long side of the lift has to be at the lower level.

**Q. What is the Inva Flexi Econ?**

A. The Econ unit can not be personalised it comes with a fixed specification and will only serve 500mm to 1000mm of travel. It is only for open through arrangements and comes in RAL 7004 light grey.

**Q. Can I view a recent installation?**

A. We have many installations around the UK and it is highly probable that we can arrange a visit to a site.